

★ Watch the instructional Videos at:
www.HarmonicaMute.com / "Using the Wah"

The Harp Wah Combo (with the handle)

First, take a moment to firmly press and hold the handle against the Harp Wah for a few seconds. This will ensure it remains firmly attached post shipping. (It is recommended that this be repeated from time to time.)



Does It Come Apart? NO – The Harp Wah is made up of two sections which are permanently sealed together.

Holding the Wah Claw Handle:

Grip the Wah with three fingers below the "hooked" part of the handle - with your index finger above the hook. (image 1)

Checkout my Workshops & Lessons at:

www.HarmonicaMute.com | Questions? info@rolyplatt.com



Attaching the Handle (if purchased separately)

★ Watch the instructional Videos at: www.HarmonicaMute.com / "Using the Wah"

Your Wah Claw handle comes with a pre-attached 3M tape strip. The handle should be attached with the bottom of the handle lined up just above the edge where the two Harp Wah sections meet (**image 1**), and with the "hooked" end, centred to the middle of the slot's length (**image 2**).

★ IMPORTANT:

Before removing the backing from the 3M tape, test the position the handle on the Wah as described above.

2. Then, using a pencil, mark a reference line along the edge of the handle, using light strokes (**image 3**).

3. Remove the backing on the tape.

4. Very, very lightly "touch" the bottom of the handle in place, so it can be easily repositioned.

4. Make adjustments, then firmly press in place. (NOTE: This should be done from time to time to ensure it remains firmly attached.)

Holding the Wah Claw Handle:

Grip the Wah with three fingers below the "hooked" part of the handle - **with your index finger above the hook.** (**image 4**)

